

POWER WAVE 32/64 "ELITE"



- Up to 64 fully programmable hardwired or wireless zones
- Supports up to 64 hardwired or wireless zones using two 32 Expander Modules via smart key Bus
- 64 wireless zones using FW-RCV wireless receiver
- Programmable and fully supervised zones as intrusion or fire
- Zone wiring options includes: normally closed, single end of line (EOL) resistor
- Multi language LCD keypads support
- 8 Programmable outputs with more than 20 programmable options
- 4 true partitions areas with separate arming
- Advanced communication
- Main formats including contact ID, SIA, voice and more
- D-LINK serial interface module for local up/download via PC
- Viewing status and trouble conditions in real time
- Fast programming using EPROM module
- 8 phone numbers
- Call back option
- Fax defeat option
- 255 event buffer with time and date stamp
- Efficient and easy installation with 4 wire smart Bus to connect keypads and modules
- 100 access codes
- "Quick arm" option
- "STAY" arming for perimeter arming per partition with selectable zones while premises are occupied
- Automatic arming/disarming at a specific time every day per area
- False alarm prevention features
- Audible exit delay, audible exit fault
- Arm/disarm bell squawk
- Urgency on entry delay
- Programmable swinger shutdown by zone
- Quick exit option

- Programmable transmission delay by zone
- AC failure, TLM trouble, and Low Battery transmission delays
- Recent close code transmission
- Opening after alarm code transmission