

POWER WAVE 16



ADVANCED 16 ZONE SECURITY SYSTEM

- 16 hardwired zones
- Up to 3 partitions and 3 part set modes
- Programmable Day zone (Chime) mode
- 3 exit & up to 16 entry delay timers
- Stay mode night arming station
- Up to 50 users
- Up to 8 programmable time zones
- Auto Arm/Disarm and control of outputs via time zones
- 8 on-board fully programmable outputs
- 256 event buffer
- Multiple communication formats
- Phone line monitoring
- Up to 6 programmable phone numbers and 4 scenarios
- Up to 16 radio devices
- Up to 20 radio keys
- Supports PowerWave & Freewave accessories

WINWAVE FULL UPLOAD/DOWNLOAD SOFTWARE PACKAGES

- User friendly windows based software for all PowerWave panels
- Bell 103 and CCITT V21 formats supported